



INSTALLATION INSTRUCTIONS

- 1) Locate center of hole "C" approximately 58" off of Finished Floor.
 - Pilot drill holes "A" & "C" through using $\frac{3}{32}$ " drill bit.
 - Drill hole "A" through with $\frac{3}{8}$ " drill bit. Drill from both sides of door to prevent tearout.
 - Drill hole "C" through with $\frac{13}{16}$ " drill bit. Drill from both sides of door to prevent tearout.
- 2) Remove cover from Chime base.
 - Place Chime base (mechanism down) on inside of door.
 - Align projection at rear of base into hole "A"
 - Spot drill 2 "B" holes using $\frac{3}{32}$ " bit, approximately $\frac{1}{4}$ " deep.
 - Mount Chime Base using 2@ #6 x $\frac{3}{8}$ " screws provided into "B" holes.
 - Pull Hinge Pin downward to enable Actuating Shaft to pass through Hinged Lever.
- 3) From outside of door, insert Actuating Shaft with Button through hole "A" and Hinged Lever.
 - Place Faceplate over Pushbutton and mount using #6 x $\frac{3}{8}$ " screws provided.
 - Push Actuating Shaft outward as far as possible through Faceplate. While holding in this position, press Hinge pin upwards, rotating Pin away from Base so that end of pin engages into nearest hole on Actuator Shaft. Push Hinge Pin upward to limit stop.
- 4) Break off excess length of Actuating Shaft at score line closest to Hinge Pin.
 - Place Cover over Chime Base by placing open slot on cover over the long tab on top of Base.
 - Tilt cover onto Base until blind slot engages short tab on bottom of Base.

AuthChimes

684

BY: **Authentic Parts**
www.authenticparts.com
 1363 Lincoln Avenue, Suite 1 • Holbrook, NY 11741
1.800.229.AUTH
 2 8 8 4

DATE 12/1/05

SCALE NONE

DRAWING NUMBER

684

DRAWN BY

BSN

CHECKED

NOT TO SCALE - DO NOT USE AS TEMPLATE